SOUND DEADENERS

1968-1977 Chevrolet Corvette Coupe

Full Set Right Right Side Transmission Front Left Floor Left Side Transmission Front Floor Right Under Left Passenger Under Seat Driver Left Seal Right Wheel Wheel Well Well Left Right Back Back Installation Instructions for Mastic Panel Pane Sound Deadener and Foil Heat Shields Only: Install pad side down. INV.# 1-SD035 (mastic)

1-SD071 (foil with pad)