
ECKLER'S® C5 and C6 Rotor Hub Cover Installation

Tools Required:
Lugwrench (19mm) Socket
22mm Socket



Torque Specifications:
Caliper Bracket Mounting Bolts – 125 ft./lbs.
Lug Nuts – 100 ft./lbs.

Step 1: Jack up car and remove wheel. See Owner's Manual or Service Manual for correct procedure of wheel removal.



Step 2: Remove wheel.



Step 3: Loosen top caliper bracket mounting bolt with 22 mm socket, then remove lower caliper bracket mounting bolt.



Step 4: Swing caliper out enough to slide hub cover onto rotor. (Do not remove caliper from bracket.)



Step 5: Install hub cover to rotor.





Step 6: Do the same for installation on rotor.



Step 7: Finished!