

C6 CORVETTE EXHAUST PORT FILLER PANEL
PART #50011 , 50012 , 50013
INSTALLATION INSTRUCTIONS

Parts Included:

Filler Panel
Adhesive Promoter
2-Self-Tapping Screws

Items Needed:

Household Isopropyl Alcohol
Philips screwdriver

YOUR PANEL COMES TO YOU WITH A PROTECTIVE LINER. DO NOT REMOVE THIS LINER UNTIL STEP 4!

1. Clean the entire underside of the factory urethane bumper, to the left and right sides of the exhaust, first with soap and water then with household isopropyl alcohol. Let dry. Then swipe once to each side with the adhesive promoter provided.
2. Pre-fit your new exhaust panel by slightly nudging the exhaust tips thru the panel so that you are able to slide the panel back far enough to allow panel to hook the back edge of the bumper and align fit as best as possible.

SPECIAL INSTALLATION INFORMATION: Almost all aftermarket exhaust systems are not manufactured to exacting standard! So it will be very likely that you may have to adjust your exhaust position as well as the evenness of the exhaust tips. The tips can be adjusted by using 2 - 1 1/2" electrical conduit pipes inserted into both tips at a time and adjusting up, down, left or right, by applying pressure in opposite directions until you achieve a parallel and level configuration. Once this has been achieved you should be able to easily slip the panel thru your Corsa or Borla exhaust so that you can insert it into position.

At this time take a look at the fit and adjust it by carefully forming by hand until you achieve a nice gapless and snug fit.

3. Once you are satisfied with the fit partially remove panel from the bumper and remove the red liner from the attachment tape. Reinstall into position press firmly to set. You will notice 2 predrilled holes on the underside of the panel using a screwdriver or screw gun insert the 2 screws (provided) to secure panel.

4. Remove protective liner.