

C6 CORVETTE DELUXE PERFORATED PLENUM COVER
PART# 50655

INSTALLATION INSTRUCTIONS

PARTS INCLUDED:

- 1-Stainless Plenum Cover**
- 1-Small Stainless Hood Cap w/Butyl putty**
- 1-Pack of Adhesive Promoter**
- 2-Lengths of Velcro Attachment Tape**

Your new cover comes to you with a protective liner. Remove liner when prompted by instructions.

1. Your new plenum cover comes to you pre-shaped however it will be necessary to further shape the cover in order to achieve a nice contoured fit. Simply form it by hand placing it in position and removing it after each adjustment as many times as is necessary until the cover matches the engines contour.
2. Prepare the fuel rail covers by scrubbing the two recessed areas with household isopropyl alcohol to remove all road grime and dirt then swipe the areas once with the adhesive promoter provided. You have been provided with two lengths of Velcro attachment tape. Place the furry side of each length into the areas you just prepared and press firmly to set.
3. Stick the hook side of the attachment tape to the furry side and expose the adhesive. Swipe the underside of your new cover with the adhesive promoter in the area that the Velcro will be attached to. Carefully place the new cover into position and press to set the attachment Velcro to the cover. You may want to remove the cover once more to make sure that the tape is completely adhered by pressing the tape to the cover with some force.
4. Replace the cover and press it down to set. Remove the protective liner. You have been provided with a small stainless hood cap to be placed over the fuel line. This cap has butyl putty on the underside simply press the cover into position.

Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.