

# C6 Chrome Grill Exterior

## INSTRUCTIONS

**NOTE:** Before you start the assembly, this is what you will need: one fork screw driver. Air ratchet or a hand ratchet. One socket of 7mm & a 10mm socket and a flat screw driver.

**Step 1:** Start by removing 5 screws at the bottom of the bumper cover.

**Step 2:** Need to remove the clip fastners which there is 8 of them. Same step for the left side.

**Step 3:** Now remove the 2 screws using a 7mm socket. After use a 10mm socket to remove the screw nut on the far left. As shown in figure 3 photo. After you will remove the inner fender piece and same for the left side.

**Step 4:** Remove 2 plastic fastners and 2 more on the right side. Then 2 more on figure 4 and 2 on the left side. After removing a total of 8 fastners, the baffle is now ready to remove.

**Step 5:** Remove 4 screws with a 7mm socket. By placing your hand inside the grill as shown in the photo you will find the screws where you can see in step 6.

**Step 6:** Remove five, 7mm screws that are attached to the grill as shown in figure 5. After that you are ready to remove the grill.

**Step 7:** Now remove the body clips from the stock grill which there are 4 clips. Then use the original body clips for the chrome grill as shown in figure 7.

**Step 8:** After installing the 4 clips to the new chrome grill, you are now ready to install. Pull the bottom of the bumper cover just enough to place the chrome grill. Once you have place it to fit, put the screws back, as shown in figure 8.

**Congratulations:** This is how your new chrome grill should look, after following the steps properly. ENJOY!!!

