

Instructions for 1968-82 Sunjacket

Thank you for the purchase of your new cover and we hope that it will give you many years of service. This cover was designed to keep water and damaging sun out of the car cabin and is a better alternative for vehicles stored inside or outside.

Remove cover from plastic bag & place cover on a clean car with the cloth side down/ vinyl side up.

The cover has four attachment points and they may change depending on year of car, whether it has a spoiler, rounded tail or high spoiler of the Pace Car.

The front of the cover has short straps and the rear of the cover has the longer straps. Orient the cover to correctly position on the car and attach as follows.

- 1) Attach the front straps to the wiper grill on the early cars and attach to the wiper arms in later cars.
- 2) Attach the strap around the driver's side mirror.
- 3) The side straps are designed to attach to the wheel well in the 10:00 position on both sides.
- 4) The rear straps were designed to go over the rear deck and attach on the rear valance of the car. They were designed with about 3 inches of stretch. The 68-to 73 cars should attach at the bottom of the rear valance. The 74 to 79 cars the rear strap can be shortened if necessary by placing a knot in the strap. The spoiler cars should have enough strap to attach either to the bottom of the tag or at the bottom of the balance

If an extension strap is needed contact us and tell us the length that is needed for spoiler cars only.

The cover is made from premium marine grade vinyl and should provide you with many years of service as long as it is taken care of in a reasonable manner.

To clean your cover use mild soap and water or a good grade vinyl cleaner.