Important... A/B Measurements CHECKING FOR HOOD CLEARANCE

To ensure adequate hood clearance, check the height of your stock manifold and compare the "A" and "B" measurements against those of the <code>Eckler's</code> manifold prior to purchase. The heights of all <code>Eckler's</code> manifolds are listed under "Installation Notes" for each model in the intake manifold section of this catalog.

Please Note: To figure carburetor pad height, add dimensions "A" + "B" and divide by 2.

For example, Performer manifold #2101: (A) $3.5" + (B) 4.6" \div 2 = 4.05"$

