

The Vette Net is shipped with two brackets, one for the right side and one for left.

To install the Vette Net, press the auto top button to allow the top to drop all the way into the trunk. (Note: The hatch cover remains open while this is happening.)

As soon as the top is down in the trunk and while the hatch is all the way open press the auto top button again to stop the process.

Install your brackets, left and right, with legs down and to the center of the car. Press auto top button to complete the closing of the hatch.

The brackets are now locked in place and the Vette Net can be inserted into the legs of the brackets.



Insert the Vette Net legs into each pipe and gently tap on the top of the net to make sure it sets all the way down into the legs.



(Optional step) Tighten the thumb screw on the brackets to set the Vette Net to your viewing preference if you like it higher, or leave it right where it is. It is your choice.

That's it! You are ready to enjoy a topless ride in comfort and pleasure.



We recommend that you store your Net and brackets in one of our storage bags away from extreme heat and cold when not in use.



