

## C1 Corvette Header steering shaft installation

Use the 5.5" bolt in the back hole and the 5" bolt in the forward mounting hole. Install support bearings as shown.

The longer 7" splined shaft installs near the rack unit and the shorter 6 7/8" shaft installs near the steering column.

Headers used are Hooker pn 2456 (painted) and 2456-1 (coated).

