Use **Pinnacle Wheel Cleaner** on all types of wheels with confidence as often as needed. This cleaner will never dull any finish aluminum, painted, polished, anodized, clear-coated, or billet wheels. It also lifts dirt and grease out of rubber. You're getting an effective tire and wheel cleaner in one!



First, clean wheels and tires with Plnnacle Gel Wheel Cleaner.



Once the tires are dry, apply a thin coat of Pinnacle Black Onyx Tire Gel.

Directions:

- 1. Rinse your wheels with water, one wheel at a time.
- Spray a light mist of Pinnacle Gel Wheel Cleaner over the entire wheel and tire surface.
- 3. Make sure it is cool to the touch and out of direct sunlight.
- 4. Wait thirty seconds before agitating the gel.
- You may need a separate tire brush and wheel brush, depending on how dirty your tires are. Tire brushes generally have stiffer bristles while wheel brushes are softer so as not to scratch.
- 6. Rinse thoroughly with a strong jet of water.
- Dry with a Cobra All Purpose Microfiber Towel to prevent water spots.
 NOTE: Do not use a tire/wheel towel on your paint.
- Now your ready for the finishing step with Pinnacle Black Onyx Tire Gel.